



Zebra: ZT411R: Adjust Print Darkness

To adjust the print darkness on your ZT411 printer, take the following steps:

1. On the home screen of the printer, tap the **Menu** button
2. Tap the **Print** icon, then **Print Quality**, then select the **Darkness** option
3. Adjust the darkness setting using the slider or **+** and **-** buttons.
 - The darkness setting ranges from **0** to **30**.
 - For **wax ribbon**, the recommended darkness setting is **10-15**.



tap the screen to return



Revision #2

Created 16 June 2025 15:11:45 by John LeBaron

Updated 2 July 2026 02:00:43 by Stan Andrus