

# ZD500R: Reset to Factory Defaults

Turn off the printer using the switch on the back.

Press and hold FEED + PAUSE while turning on the printer.

Continue holding FEED + PAUSE until the first control panel light turns off.

The printer configuration is now reset to the factory default values.

---

Revision #1

Created 15 May 2025 16:51:03 by John LeBaron

Updated 15 May 2025 16:54:28 by John LeBaron