

Zebra ZD500R: Reset to Factory Defaults

Turn off the printer using the switch on the back.



Press and hold FEED + PAUSE while turning on the printer.



Continue holding FEED + PAUSE until the first control panel light turns off.

The printer configuration is now reset to the factory default values.

