



Zebra ZT411 - Adjust Print Darkness

To adjust the print darkness on your ZT411 printer, take the following steps:

1. On the home screen of the printer, tap the **Menu** button
2. Tap the **Print** icon, then **Print Quality**, then select the **Darkness** option
3. Adjust the darkness setting using the slider or + and - buttons.
 - The darkness setting ranges from **0** to **30**.
 - For **wax ribbon**, the recommended darkness setting is **10-15**.



Tap the home icon to return to the screen to return



Revision #1

Created 16 June 2025 15:11:45 by John LeBaron

Updated 16 June 2025 16:18:37 by John LeBaron